

# Intensive Plus (FSP)

advantage: comfort | use: healthcare, office, industrial, education

supports  
**500**  
pounds

Highlighted by a 500-lb. capacity and executive-style comfort, this series is designed for continuous, 24/7/365 use and backed by a 5-year warranty.



- Cloth and vinyl upholstery styles available to match various workspace requirements.
  - Generously proportioned, contoured 20" wide x 23" high S-style backrest with lumbar and kidney support.
  - Saddle-shaped, contoured seat with sewn seams to help inhibit foam compression and maintain profile, waterfall front and internal seat board bumperguard.
  - Black powder-coated paint finish standard on metal parts.
  - Pneumatic provides seat height adjustment range to accommodate many tasks.
  - 5-point star-shaped 27" diameter polished aluminum base.
- Available with heavy-duty glides (Model FSP-M-HG-XF-XA-06) or 3" diameter, dual-wheel casters that are load rated to 165 pounds each (Model FSP-M-IPR-XF-XA-06).

Shown here:  
**Intensive Plus with optional height-adjustable armrests with self-skinned urethane pads, medium seat height range**



**Executive Seat Control with Seat Slider:** pneumatic seat-height adjustment and backrest height adjustment, seat and backrest swivel/tilt in unison, tilt-tension control knob and single lever seat tilt lock in any position. Seat Slider allows seat depth adjustment range of up 2.5" with locking positions every 0.5".



ordering information | january 2024

**Intensive Plus | Standard Components**

21"W x 19"D x 31"H seat with executive seat control w/seat slider adjustment range of 2.5", pneumatic seat height adjustment and backrest adjustment, seat and backrest swivel/tilt in unison, tilt-tension control knob and single-lever seat tilt lock, 20"W x 23"H backrest with lumbar and kidney support, grade 2 upholstery

Model#	Seat-Hgt.	Compatibility
FSP-M-IPR-IP-XF-XA-06	Medium, 20"-25"	Standard Bench
FSP-M-HG-IP-XF-XA-06	Medium, 20"-25"	Standard Bench

Ask about special and custom orders.

optional components

Component	MFG Code	Description
Armrests	ISAS	Height adjustable with self-skinned urethane pads
Miscellaneous	SW	Skid wrapping; net cost per pallet
	FM	Memory Foam

upholstery

MFG Code	Description
COM	Customer's own material
Grade 2	Comes standard. Contact BioFit for other options.

performance packages

Category	Class	MFG Code
Clean Room	ISO 8	ISO8
	ISO 7	ISO7

**WARNING:** This product can expose you to chemicals including wood dust, which is known to the State of California to cause cancer. For more information go to [www.p65warnings.ca.gov](http://www.p65warnings.ca.gov).

## Make an impact with our Scepter back

The modularity of the BioFit Foundation Seating Line enables impact professionals to pair the executive-style Scepter back with any of our Foundation seat options found on page 48 of this catalog. Take advantage of the ergonomic benefits of our Scepter back with your favorite chair configuration to enjoy its generously proportioned and contoured shape while supporting both your lumbar and kidney areas in comfort.

Shown here: **Chair featuring Scepter back with A seat and R base, with optional components including executive-style control and height-adjustable armrests.**

